



## AMB Trans x260 Transponder Mounting Locations

### **Super Late Model and Late Model**

Transponder must be mounted on the left frame rail, in a vertical position no more than 8" and no less than 6" ahead of axle tube center line.

### **Midwest Sportsman**

Transponder must be mounted on the right side firewall, frame rail, or roll cage in a vertical position no less than 75" back from the most forward point of the front bumper cover.

### **Slinger Bee's**

Transponder must be located 85" from the most forward point of the front nosepiece. The transponder must be mounted in a vertical position with a 3" Diameter hole.

### **Area Sportsman**

Transponder must be mounted 165" from the most forward point of the front nosepiece. The transponder must be mounted in a vertical position.

NOTE: The transponder cannot be mounted more than 24" above the racing surface. Please protect your transponder from extreme heat (headers, manifolds, exhaust outlets) and debris. Also make sure the transponder is properly charge each week.